

S P I D E R W E B マルチタック ホットメルト接着剤

取扱説明書

1. 形状は7mm×100~200mmのスティックタイプと3mmΦのペレット形状。
ご使用するグルーガン、塗工機に合わせて形状を選んでください。
2. 完全な液状にするための加熱温度は134℃以上が必要となります。
3. 160℃以上でご使用しないでください。
4. 接着素材は紙、布、木、合皮、金属、ガラス、陶器、プラスチックなど。
シリコン、フッ素にはご利用できません。
5. 接着硬化時間は室温で5分~7分見てください。
環境、素材により差異はあります。
6. 保管については暗所、35℃以内で保管願います。
7. ご使用に関する安全上の注意事項
下記QRコードを読み取り確認願います。



製品 SDS データを表示

お問い合わせ

株式会社フジキ 事業開発部

〒530-0044 大阪府大阪市北区東天満 1-5-8

電話番号：04-7128-8844 メールアドレス：fujiki_technical_center@e-fjk.co.jp

ホームページ：<http://www.e-fjk.co.jp/spiderweb/>

SPIDER WEB Multi tack Hotmelt Bond

User's manual

1. There are two types of this product, a 7mmφ*100-200mm stick and a 3mm pellet. Please select the shape according to the glue gun or coating machine you use.
2. In order to make the Multi tack completely liquid, a heating temperature of 134°C or more is required.
3. Please do not use this product at 160°C or higher.
4. Materials that can be glued using Multi tack: paper, cloth, wood, synthetic leather, metal, glass, pottery, plastic, etc. It cannot be used for silicone or fluorine.
5. The curing time of the glue is 5 to 7 minutes at room temperature.
(There are differences depending on the environment and materials.)
6. Please store this product in a dark indoor space of 35°C or less.
7. Regarding use: Safety precautions
Please check the QR code below.



Check the SDS data.

Contact information

Fujiki Co., Ltd. Business Development Department Technical Center

#4F Sensyu bldg, 1-5-3, Tennodai, Abiko-City, Chiba, 270-1143, Japan

TEL : +81-4-7128-8844 E-mail : fujiki_technical_center@e-fjk.co.jp

HP : <http://www.e-fjk.co.jp/spiderweb/>